

# AW-FP200 Addressable Fire Alarm System Installation Guide

ASENWARE LTD



## **Content**

O 1 System Introduction

O2 Address Programming

03 System Wiring

04 System Operation



O1
PART ONE

# **System Introduction**

#### **System Introduction**




#### **Feature**

- [Panel to panel netwrok] Every panel can reset, silence, and evacuate other connected panels. supprt to connect with AW-FP128 & AW-FP100 too
- [Wireless] Each loops support 10 wireless group, maximum can connect 1600 wireless devices
- [Multi language] Vietnamese, Spanish, Thailand Russian, French, Portuguese available
- [Loop power supply] The whole addressable loop is two wire only
- [Graphic monitor] available
- [GSM] 4G 10 mobile phone numbers







#### **System Introduction**



#### AW-FP200 Addressable Fire Alarm Control Panel



AW-FP200 series addressable fire alarm control panel is designed with 7-inch LCD display touch screen with button operation, easy to operate, and nice human-computer interface.

This machine can be connected to 8 loops. Each loop can be connected to 250 devices, such as smoke detectors, temperature detectors, input/output modules, each loop can be connected to 10 groups of wireless loops, a group of wireless loops can be connected to 20 devices, such as smoke detector, temperature detector, input and output module, etc.

#### **YOUTUBE operating videos:**

How to Wire and Operate AW-FP200 Addressable Fire Alarm System <a href="https://youtu.be/FN1eQO7BPmY">https://youtu.be/FN1eQO7BPmY</a>

#### **System Introduction**



#### AW-FP200 Addressable Fire Alarm Control Panel



- 7-inch color LCD display, touch screen operation
- All addressable devices use a two-wire system
- A wired loop can connect 250 wired addressable devices, including 10 groups of wireless loops
- One set of wireless loops can connect to 20 devices
- Max 8 loop cards can be installed
- Up to 999 records of history can be saved (save when power off)
- Multiple access levels can be set
- It has a rechargeable backup battery
- Can simply judge the running status of the machine based on the LED lights
- Automatic search device
- Each of the 8 hosts CAN be controlled remotely
- USB software upper computer to check and set the device status and fire history records
- It can bind 10 mobile phone numbers to receive host alarm information (The GSM module must be added)

#### **AW-D106A Wireless Strobe sounder**





Operating Voltage	18~28V DC @Loop
Operating current	standby status ≤25mA, alarm status ≤100mA
Operating Frequency	433MHz
Alarm SPL	≥100dB@1m
Flash Period	1 Time/Sec
Protection class	IP30
Environmental	Temperature range: -10 to 50°C (14~122°F)
	Humidity: 5 to 95% RH, non-condensing
Materials and color	ABS red
Application	For indoor use only
Mating Host	Addressable fire alarm control panel
Encoding	Address from 1 to 250 optional
Size	154mm* 115mm* 50mm
Weight	188.5g (without package) 224.5g (with package)

#### AW-D603L Wireless smoke detector





Operating Voltage	3VDC (with battery CR17450 / CR17455)
Operating current	monitoring status≤8uA, alarm status≤120mA
Operating Frequency	433MHz (418MHz to 448MHz)
Smoke Alarm Sensitivity	0.18-0.3dBM
Wireless transmit power	+20dB
Alarm SPL	≥85dB /3m
Protection class	IP30
Indicator	Normal: blinking Alarm: lighting
Environmental	Temperature range: 0 to 40°C (32~104°F) Humidity: ≤93% RH, non-condensing
Materials and colors	ABS, white
Mating Host	AW-FP100 addressable fire alarm control panel
Encoding	Address from 1 to 250 optional
Size	105mm* 105mm* 41mm (with cover)
Weight	About 120g
	1977)

#### AW-D604L Wireless heat detector





Operating Voltage	3VDC (with battery CR17450 / CR17455)
Operating current	monitoring status≤8uA, alarm status≤120mA
Operating Frequency	433MHz (418MHz to 448MHz)
Fix temperature Alarm	57°C (135°F) A2R
Rate of rise Alarm	≥10°C/2M A2R
Wireless transmit power	+20dB
Alarm level	≥85dB /3m
Protection class	IP30
Indicator	Normal: blinking Alarm: lighting
Environmental	Temperature range: 0 to 40°C (32~104°F) Humidity: ≤93% RH, non-condensing
Materials and colors	ABS, white
Mating Host	AW-FP100 addressable fire alarm control panel
Encoding	Address from 1 to 250 optional
Size	105mm* 105mm* 50.2mm (with cover)
Weight	About 120g

# AW-D605L Wireless smoke and heat combined detector





Operating Voltage	3VDC (with battery CR17450 / CR17455)
Operating current	monitoring status≤8uA, alarm status≤120mA
Operating Frequency	433MHz (418MHz to 448MHz)
Smoke Alarm Sensitivity	0.18-0.3dBM
Fix temperature Alarm	57° C (135° F) A2R
Rate of rise Alarm	≥10°C/2M A2R
Wireless transmit power	+20dB
Alarm level	≥85dB /3m
Protection class	IP30
Indicator	Normal: blinking Alarm: lighting
Environmental	Temperature range: 0 to 40°C (32~104°F) Humidity: ≤93% RH, non-condensing
Materials and colors	ABS, white
Mating Host	AW-FP100 addressable fire alarm control panel
Encoding	Address from 1 to 250 optional
Size	105mm* 105mm* 50.2mm (with cover)
Weight	About 120g
Million Control	

#### AW-D101 Addressable smoke detector





Model	AW-D101
Operating voltage	18~28VDC @Loop
Operating current(@Loop 24VDC)	Monitoring status≤2.5mA, Alarm status≤3mA
Application	For indoor use only
Wiring	The promise of two bus system(Loop in, Loop out)
Smoke alarm sensitivity	0.18~0.3dB/m
Environmental	Temperature range: -10~50°C (14~122°F) Humidity: 5 to 95% RH, non-condensing
Materials and colors	ABS, White
Mating host	AW-FP100 series fire alarm control panel
Size	ф 99.8mm* 48.2mm
Weight	About 85g

#### AW-D102 Addressable heat detector





Model	AW-D102
Operating voltage	18~28VDC @Loop
Operating current(@Loop 24VDC)	Monitoring status≤2.5mA, Alarm status≤3mA
Application	For indoor use only
Wiring	The promise of two bus system(Loop in, Loop out)
Fixed temperature alarm	57°C(135°F) A2R
Rate-of-rise alarm	7.1°C/5s A2R
Environmental	Temperature range: -10~50°C (14~122°F) Humidity: 5 to 95% RH, non-condensing
Materials and colors	ABS, White
Mating host	AW-FP100 series fire alarm control panel
Size	ф 100mm* 46.5mm
Weight	About 65g

### AW-D138 Addressable smoke and heat detector





Model	AW-D138
Operating voltage	18~28VDC @Loop
Operating current(@Loop 24VDC)	Monitoring status≤1.5mA, Alarm status≤2.5mA @24VDC
Application	For indoor use only
Wiring	The promise of two bus system(Loop in, Loop out)
Smoke alarm sensitivity	0.18~0.3dB/m
Fixed temperature alarm	57°C (135°F) A2R
Environmental	Temperature range: -10~50°C (14~122°F)
	Humidity: 5 to 95% RH, non-condensing
Materials and colors	ABS, White
Mating host	AW-FP100 series addressable fire alarm control panel
Size	φ 100mm* 55.7mm installed in base
Weight	About 120g

#### **AW-D116 Addressable annunciator**





Model	AW-D116
Operating voltage	18~28VDC @Loop
Operating current(@Loop 24VDC)	Monitoring status≤30mA
Wiring	The promise of two bus system(Loop in, Loop out)
Protection level	IP 30
Environmental	Temperature range: -10~50°C (14~122°F)
	Humidity: 5 to 95% RH, non-condensing
Mating host	AW-FP100 series fire alarm control panel
Size (L*W*H)	172mm* 128mm* 39mm

# AW-D135A Addressable manual call point





Model	AW-D135A
Main Voltage	Loop 24V
Operating current	monitoring status≤2mA, alarm status≤15mA
Application	For indoor use only
Wiring	The promise of two bus system(Loop In+, Loop In -)
Protection class	IP30
Indicator	Red alarm indicator flashes when it is under normal condition, press the manual button lit work
Environmental	Class A temperature range: -5 to 40°C (23~104°F) Humidity: 5 to 95% RH, non-condensing
Materials and colors	ABS, red
Mating Panel	AW-FP100 addressable fire alarm control panel
Encoding	address from 1 to 250 optional
Size	99mm* 92mm* 66mm (with cover)
Weight	about 95g
-	

#### AW-D109 Addressable fire alarm bell





Model	AW-D109
Operating voltage	18~28VDC @Loop
Operating current(@Loop 24VDC)	Standby status≤3mA, Alarm status≤50mA
Wiring	The promise of two bus system(Loop in, Loop out)
Alarm SPL	≥98 dB @1m
Environmental	Temperature range: -10~50°C (14~122°F)
Environmental	Humidity: 5 to 95% RH, non-condensing
Materials and colors	ABS(Base),Iron, Red
Mating host	AW-FP100 series fire alarm control panel
Size(L*W)	110mm* 110mm
Net weight	About 630g



02

# **Address Programming**

# **Programming for strobe sounder**





AW ASENWARE

One Power Date

Rest Write

3
3

Connect the programmer connection cable to the connection port of the strobe sounder.

Choose "Group: 001", "Addr: 002", and "Panel:

001" on the programmer.

Group: 001

**Addr:** 002

Panel: 001

## Programming for strobe sounder





Group: 001

Addr: 002

Panel: 001

Success

Press "Write" button to write the address, and the screen will show "Success". Then pull out the programmer connection cable.

### Programming for manual call point







Connect the programmer connection cable to the connection port of the manual call point.

Group: 001

Addr: 002

Panel: 001

"Group: 001", "Panel: 001" remain unchanged. The first device is wireless strobe sounder, and the address of the second device can be linked with the first device, so the address of the manual call point can still choose "Addr: 002".

## Programming for manual call point





Group: 001

**Addr:** 002

Panel: 001

Success

Press "Write" button to write the address, and the screen will show "Success". Then pull out the programmer connection cable.

## **Programming for smoke detector**







Press and hold the button of the smoke detector to turn it on, after hearing a "beep", press and hold the button again to enter the programming mode.

"Group: 001", "Panel: 001" remain unchanged, press "Inc" button to choose "Addr: 003".

Group: 001

**Addr:** 003

Panel: 001

#### **Programming for smoke detector**







Press "Write" to write the address, and the screen will show "Success".

Meanwhile, the smoke detector will beep for once.

Group: 001

Addr: 003

Panel: 001

Success

Press the button on the smoke detector to exit the programming mode.

#### **Programming for heat detector**







Press and hold the button of the heat detector to turn it on, after hearing a "beep", press and hold the button again to enter the programming mode.

"Group: 001", "Panel: 001" remain unchanged, press

"Inc" button to choose "Addr: 004".

Group: 001

Addr: 004

Panel: 001

### **Programming for heat detector**





Group: 001

Addr: 004

Panel: 001

Success

Press "Write" to write the address, and the screen will show "Success". Press the button on the heat detector to exit the programming mode.

# Programming for smoke and heat combined detector







Press and hold the button of the combined detector to turn it on, after hearing a "beep", press and hold the button again to enter the programming mode. "Group: 001", "Panel: 001" remain unchanged, press

"Inc" button to choose "Addr: 005".

Group: 001

Addr: 005

Panel: 001

# Programming for smoke and heat combined detector





Group: 001

Addr: 005

Panel: 001

Success

Press "Write" to write the address, and the screen will show "Success". Press the button on the combined detector to exit the programming mode.

# Programming for addressable annunciator for addressable system







Connect the programmer connection cable to the connection port of the addressable annunciator.

"Group: 001", "Panel: 001" remain unchanged, press

"Inc" button to choose "Addr: 006".

Group: 001

Addr: 006

Panel: 001

# Programming for addressable annunciator for addressable system





Group: 001

**Addr:** 006

Panel: 001

Success

Press "Write" to write the address, and the screen will show "Success".



O3
PART THREE


# **System Wiring**

# Panel wiring connection






There are the wiring ports of 8 loops, and they are marked from LOOP 1 to LOOP 8 respectively.




The terminal wires are connected up and down, on the left is LOOP IN, and on the right is LOOP OUT.



# **System Wiring**Smoke detector wiring






The red and blue wires are the wires connected to the panel.

Connect them to port 2 and port 5 of the smoke detector base.

#### **AW.** ASENWARE

# Addressable manual call point wiring



Connect the wires from the smoke detector base to the next product: addressable manual call point.

Connect the wires to the "LOOP IN" and "LOOP OUT" ports of the manual call point.


#### **AW.** ASENWARE

### Addressable strobe sounder wiring




Connect the "LOOP OUT" wires of the manual call point base to the next product: addressable strobe sounder.

Connect the wires to the "LOOP IN" and "LOOP OUT" ports of the strobe sounder.



# Heat detector wiring







Connect the "LOOP OUT" wires of strobe sounder to the next product: the heat detector base.

Connect the wires to port 2 and port 5 of the heat detector base.

# Addressable annunciator wiring







Connect the wires of the heat detector base to the addressable annunciator.

Connect the wires to the "LOOP IN" and "LOOP OUT" ports of the addressable annunciator.

If you need to connect more products, you only need to connect the wires from the "LOOP OUT" port of the annunciator to other products.



04
PART FOUR

## **System Operation**

#### **Panel Menu**



#### Menu

1. Panel Setup

2. Status & Operation

3. Register

4. Zone Setting

Configuration TCP/IP CAN **GSM** Change password Printer

settings

Customize type Fault shield

Wired devices Wireless devices

5. History

Fire Fault Linkage Operation 6. USB Setting

Settings import Settings export

7. Panel Info

8. Restore **Factory Settings** 


#### **Panel Buttons**



Button	Function
1., 2ABC 3DEF  4GHI 5JKL 6MNO  7PORS 8TUV 9WXYZ  * 8 0 0 4 1	Input numbers
	Move cursor up or page up
	Move cursor down or page down
	One to the left
	Move it one place to the right
Enter	Enter the Confirm key
Login	The login permission page is displayed
Menu	The detailed menu bar page is displayed
Delete	Used to delete the key when the input is incorrect

Button	Function
Cancel	Return to the previous page in the menu and submenu
F.A DIS/EN	Disable/Enable F.A Output
S.C DIS/EN	Disable/Enable S.C Output
Test	Run LED.
Evac	Evacuate: Activate all output device (change in Register)
Buzzer Silence	Silence Buzzer on Panel
Sounder	Silence S.C Output and all sounder devices (such as horn strobe and bell)
Reset	Reset the panel, and clean all alarm.
F.P.E DIS/EN	Disable/Enable F.P.E Output

#### Home screen






- By touch the menu button on the screen, users can manipulate and view more system content.
- By touch the LOGIN button on the screen, users can enter the system with the corresponding access level password.
- By touch the exit button, the user can exit the current access level and return to level 1.
- When anything happens, they will be displayed in the event column corresponding to the main screen. For example, the detector sends a fire alarm signal to the control panel, which will be displayed on the Fire page.
- Disable information for devices or Zones will be displayed in the Disable column. When any fault occurs, it will be displayed in the Fault column.
- The information when the strobe sounder is activated will be displayed in the Activation column.
- Press the corresponding Label to switch pages.

### Log in to the account






User: Super Administrator

Password: 1111

#### **AW.** ASENWARE

### Panel Setup

Panel Setup —— Configuration



First, press "MENU", choose "PANEL SETUP", "CONFIGURATION", and set up the basic information of the panel.

Enter your own "PANEL NAME".

Below, you can set up "SCREEN SAVER", "LANGUAGE" and "TIME SETUP". After setting, press " $\sqrt{}$ " to save.

### Panel Setup



Panel Setup —— TCP/IP

TCD/ID SETTING


				OI /II OLI III			
PANEL SETUP		Â	1	Mode: Remote IP:		Local Port: Remote Port	
CONFIGURATION	TCP/IP		2	Mode:	V	Local Port:	
CAN	GSM		2	Remote IP:	],[],[]	Remote Por	- LONG AND AND ADDRESS OF THE PARTY OF THE P
			 2	Mode:		Local Port:	
CHANGE PASSWORD	PRINTER		3	Remote IP:	1414	Remote Por	t:
CUSMOMIZE TYPE	FAULT SHIELD SETTINGS	<b>←</b>		Local IP: Local Subnet Mask: Local Gateway:			Net Enable:
				Local DNS:			

Set up the Ethernet according to your needs. In "Net Enable", you can choose to turn on or turn off the Ethernet. After setting, press " $\sqrt{}$ " to save.

## **System Operation**Panel Setup



#### Panel Setup —— CAN



Next, set up "CAN" network. It is the connection between panel and panel.

You can choose to turn on or turn off the "CAN" network.

"2" is the panel number, "100Kbps" is the baud rate (optional), and the baud rate of each panel should be the same.

If there are other connected panels, you can press to turn on the corresponding ones.

Below is whether to send or receive the signal of the panel, they are turned on by default.

After setting, press " $\sqrt{}$ " to save. In this way, if one of the panels has fire alarm information, fault information, etc., they will be showed on the other panels as well.

### Panel Setup



Panel Setup —— GSM



Next, set up "GSM", which is to send fire messages to mobile phones using 4G module.


Set up "GSM Enable", "Send Fire", "Send Fault", and "Send Operation".

Below, you can enter phone numbers for receiving text messages. Enter the dialing code + mobile phone number, and press " $\sqrt{}$ " to save.

## **System Operation**Panel Setup



Panel Setup —— Change Password



Press the PASSWORD CHANGE button, the user can change the password for login. The passwords for access level 2 and access level 3 can be modified through the interface shown in the figure 8 below.


The access level 2 user corresponding to the Administrator; the user access level 3 corresponding to the Super Administrator.

Developer is a user of access level 4, and only the manufacturer and the person trained by the manufacturer to change or modify the system can be authorized to access this level.

### Panel Setup



Panel Setup —— Printer




In the print setting window, as shown in Figure 10, set whether to enable the print module and set Fire, Fault and Operation information respectively. OFF means not disabled, ON means disabled.

Note: The user must click " $\sqrt{}$ " to confirm the change.

### Panel Setup



Panel Setup —— Customize Type



When new products are released, users can add device types to adapt. Detailed usage methods will be provided when new products are released.


Note: The user must click " $\sqrt{\phantom{a}}$ " to confirm the change.

SN:	TypeName:		
	/ <u>A</u> <u>V</u>		4
USTOM Name:	IZETYPE		â
		Enabled	<u> </u>

## **System Operation**Panel Setup



Panel Setup —— Fault Shield Settings



"Fault Shield Settings" is to shield different faults of the system.


For example, if there is no battery, turn on "Battery Fault", after saving, the panel will no longer show battery fault information. Others are the same, after turning on the "Fault Shield" of other options, the panel will no longer show the corresponding fault information.

That is, the corresponding fault information will no longer be showed at "Fault" on the panel home page.

#### Register







Second, press "REGISTER" at "MENU" to register the connected devices to the panel.

Press "WIRED DEVICE" to search for wired devices. You can search for devices in one loop, or you can search for devices in all loops. Normally, we choose to search for devices in all loops.

Wait for 230 seconds


On the screen are all the devices that are searched, press " $\sqrt{}$ " to save.

## **System Operation** Register




#### Register—— Wireless Devices










"WIRELESS DEVICE" is to register the wireless devices, they need to be manually added to the panel. There is Group 1 of wireless horn strobe, and the address and group of it is showed on the screen. Press "Wireless horn strobe", add the wireless manual call point to the group.

Add wireless manual call point to address 1. Press "Product Type", choose "Wireless MCP", and choose "1" for "Zone" and "Link Group", turn on "Reg.", press "√" to save. If there are more wireless devices, just continue to add them according to the above method.

## **System Operation**<br/>Zone Settings



#### **Zone Settings**




Next, press "ZONE SETTINGS" to set up the zones.

You can choose to turn on or off "Setting All Devices in Zone 1" and "Same Zone in the Whole Network".

According to "Zone" and "Link Group" of the devices, press "Zone 1", open the corresponding Link Group.


Press " $\sqrt{}$ " to save.



#### History



#### History



In "History", you can see "Fire History", "Fault History", "Linkage History", and "Operation History".

"Clear History" requires "Super Administrator" level to operate.

# **System Operation**USB Settings



#### **USB Settings**



Next is "USB Setting", which is the import and export of data.

The USB interface is in here, inside the panel, next to the motherboard.






**USB** interface

#### Panel Info



#### Panel Info




Next is "Panel Info", which is the basic information of the panel. If level 2 and access level 3 forgets the password, the submenu user list can help them retrieve the password or change the password. Each user level can only modify its own level of password or subordinate password.

# **System Operation**Restore Factory Settings



#### **Restore Factory Settings**



"Restore Factory Settings" is to restore factory settings of the panel.



## Thanks for watching